



Firestone

SPECIALTY PRODUCTS

PondGard Installation Detail 3-

Deploying a Geotextile Downslope

	<p><u>Step 1-</u> Starting at the apex of the slope, deploy the geotextile downhill.</p> <p><u>Step 2-</u> If necessary; apply a temporary ballast or mechanical attachment to the soil.</p>
	<p><u>Step 3-</u> Trim the geotextile to fit.</p>

This Detail featured these Firestone Specialty Products:

Item

- PondGard geotextile

Part Number(s)

Varies by Size