

Firestone

SPECIALTY PRODUCTS

PondGard Installation Detail 4-

Deploying a Geotextile Up a Slope



Step 1- Unroll the geotextile.

Step 2- If necessary; apply a temporary ballast or mechanical attachment to the soil.



Step 3- Trim the geotextile to fit.

This Detail featured these Firestone Specialty Products:

Item

- PondGard geotextile

Part Number(s)

Varies by Size