



Firestone

SPECIALTY PRODUCTS

PondGard Installation Detail 5-

Using Sod Staples to Hold Geotextiles Against Wind Uplift

	<p><u>Step 1-</u> Use sod staples to hold the geotextile in place.</p>
	<p><u>Step 2-</u> Remove all bent or excess staples that pose a hazard of puncturing the PondGard membrane.</p>

This Detail featured these Firestone Specialty Products:

Item

- PondGard geotextile

Part Number(s)

Varies by Size