

# Firestone

## SPECIALTY PRODUCTS

### **PondGard Installation Detail 6-** Unrolling PondGard Geomembrane (Downslope)



**Step 1-** Starting at the apex of the slope; unroll the PondGard in the direction shown on the outer wrapper.



**Step 2-** Use scissors to trim the PondGard to fit.

**Note:** Do not use a knife to trim PondGard.

#### **This Detail featured these Firestone Specialty Products:**

Item

- PondGard EPDM Rubber Membrane

Part Number(s)

Varies by Size