



# DECOBASIN

**DecoBasin**  
Item #60000



## Instructions

### STEP 1

- Dig a hole approximately 24" wide and 18" deep with the surrounding soil sloping toward the DecoBasin. Place the DecoBasin in the hole. Then, level and backfill the basin into its final position (Ex. 1).




### STEP 2

- Center the splash skirt over the lid of the DecoBasin. The splash skirt allows water to flow back into the DecoBasin, reducing water loss due to splash-off (Ex. 2).

### STEP 3

- Connect the water feature plumbing to the water pump (not included). Then, place the pump into the DecoBasin with the plumbing running through the center hole (Ex. 3).



### STEP 4

- Set and level the water feature on top of the basin. Then, cover the lid and splash skirt with a layer of 1" to 2" gravel or river stone (not included). Fill the DecoBasin with water, plug in the pump, and enjoy (Ex. 4).

